



SOFT LIQUID CLEANSER

MAGIC KITCHEN CLEANER

FEATURES

- Ideal for use in sinks, cookware, stove cooktops, ovens, countertops, plates and silverware
- Cleans and polishes
- Removes stubborn marks and stains from ceramics, fiberglass, and stainless steel
- Reduces bacterial growth
- Ideal for use in kitchens

PROPERTIES

Appearance: Viscous, green liquid

pH: 6.0 - 7.0

Solubility in water: Soluble

Storage stability: Keep away from high temperatures and open flames

Flammability: Non-flammable


Packaging: 12x32 oz quart/ case

Magic Kitchen Cleaner is a specially formulated cream that removes food grime, stains from glass, casserole dishes, stainless steel utensils, enamel-coated cast iron, and other cookware.

Magic Kitchen Cleaner can also remove hard water stains, salt deposits, rust, scale, and other stubborn spots and stains. It contains grease cutting detergents that facilitate the removal of greases.

To use, apply onto the surface to be cleaned with a sponge, pad or cloth. Loosen soil with gentle scrubbing action and rinse thoroughly with water. Dry with sponge or cloth. Refer to the label and SDS for additional instructions and precautions. The information contained in this safety sheet is aimed at creating a guide for the selection and use of the product. However, we are not responsible for any use not recommended by ChemTron.

ChemTron
3911 SW 47th AVE
Davie, Florida 33314
Tel: (954) 584 - 4530
Fax: (954) 584 - 4531
www.chemtron.com



- Properties are typical and subject to usual manufacturing tolerances.